

# FRAMA Fx Series 5

## **USER MANUAL F-LINK 2**




### **Table of contents**

LAN connectivity	2
LAN wireless connectivity	6
Appendix	11

# LAN connectivity


The LAN connectivity works for the Frama Fx Series 5.

## LAN connection



Plug in the **Power Adapter** and wait until both status lights are lit

Plug the **LAN cable** between the F-Link 2 and the customer network



On your **Mobile Phone**, look in wireless setting for available networks. Search for a network that starts with: **Connect-A001245** Select this network and enter the **Password: Nconnect**

Open an internet browser on this phone and enter the following URL: **https://192.168.123.1**

You may see a warning that the connection is not private. Please click on the **Advanced-tab** in your browser to proceed to **https://192.168.123.1**

Now, you will be allowed to sign in. Use the following login:

**Login: admin**  
**Password: admin**

## Configuration of Modem / Router mode for F-Link 2

**Connect** | HOME | NETWORK | LOG | INFO | SETTINGS | USER GUIDE

LAN

ADDRESSING TYPE:	DHCP
STATUS:	UP
MAC ADDRESS:	90:1f:00:00:00:01
IP ADDRESS:	
IP VS LINK:	192.168.100.1/255.255.255.0
NETMASK:	
GATEWAY:	
RX BYTES:	139155
TX BYTES:	17819

Wireless Access Point

ACCESS POINT NAME:	Connect40124519A19460005
STATUS:	UP
MAC ADDRESS:	02:1f:24:24:00:00
IP ADDRESS:	192.168.123.1
IP VS LINK:	192.168.123.1/255.255.255.0
NETMASK:	255.255.255.0
GATEWAY:	
RX BYTES:	560030
TX BYTES:	3414485

DNS

DNS 1:	10.207.40.139
DNS 2:	10.207.40.139

### Step 1:

**Note:** With your mobile phone, you must be connected with the box to modify settings

On **Home** page: the LAN status should be **UP** and the IP address should be different from 192.168.123.1

**Connect** | HOME | NETWORK | LOG | INFO | SETTINGS | USER GUIDE

LAN | WIRELESS STATION | WIRELESS ACCESS POINT

### Change parameters for Lan Interface

DHCP:

Static:

Ip address:

NetMask:

Gateway:

DNS 1:

DNS 2:

### Step 2:

Go to **NETWORK/LAN** page

Next, set the following parameters:  
Select **Static** (not DHCP)

Sample settings. Ask the Network administrator for correct IP credentials:

IP address: **192.168.99.1**  
 NetMask: **255.255.255.0**  
 Gateway: **192.168.0.1**  
 DNS 1: **8.8.8.8**  
 DNS 2: **8.8.4.4**

Then, click the **Submit** button

Success Information

192.168.123.1 indique  
lan success

**Connect** | HOME | NETWORK | LOG | INFO | SETTINGS | USER GUIDE

IS/IN/IX | IJWJ | PROXY | LOGIN/PWD | RESET

### Change parameters for IS machine

Name server for On-Line Services:

Port number for On-Line Services:

Name server for Postal Core:

Port number for Postal Core:

### Step 3:

On **Settings / IS/IN/IX** enter **URL Settings** of F-Link 2

#### CH

On- Line Services: **chfr-MeterServices.link0-neopost.com**  
 Server Postal Core: **chfr-MeterServices.link0-neopost.com**  
 Port number: **443**


#### UK

On- Line Services: **ukfr-MeterServices.link0-neopost.com**  
 Server Postal Core: **ukfr-MeterServices.link0-neopost.com**  
 Port number: **443**

Then, click the **Apply** button

Therewith the configuration of the F-Link 2 has been completed.

## Configuration of Fx Series franking systems






Plug in the **LAN cable** to the Internet wall socket

Plug in the **LAN cable** to the base and the Internet wall socket

Power up the F-Link 2

## Franking Systems Configuration



### Step 1:

**On the Franking Systems go to Supervisor Mode (Manger)** and then to


- **Erweiterte Einstellungen (CH)**
- **Advanced Settings (UK)**

**Communication Setting** and configure following parameters

Next, select **LAN settings**


In **LAN configuration** select **DHCP Auto**

Confirm with **OK**




Also select **DNS Auto**  
Confirm with **OK**

**Note:** All next screens, just confirm until you reach **Proxy** menu



Set Proxy to **ON**  
Confirm setting with **OK**




In Proxy configuration enter the following credentials:

Ask the customer IT administrator for correct credentials

- Proxy-URL **192.168.99.1** (static **IP address** from the F-Link 2)
- Proxy-Port **8080**
- If required: **Proxy Domain name, User name and Password**

Confirm with **OK**


**Note:** All next screens, just confirm with **OK** until you reach **Communication settings** again



**Step 2:**


In **Menu**

- **System Info (CH)**
- **Maintenance (UK)**



Select

- **Netzwerkeinstellungen (CH)**
- **Network Advanced Settings (UK)**



In Network configuration enter the following credentials:

Menu **TCP Output Port**

- TCP output port: **4444**

Confirm with **OK**



Menu **Redirection URI**

- Set Redirection to **ON**

Confirm with **OK**

- Redirection URI (OLS): **ols**
- PSD Redirection URI: **postal**

**Note:** Write URI information in small letters


Confirm with **OK** until you return to **Network Configuration**

**Congratulation!** The F-Link 2 and the Franking Systems are successfully configured. However, make sure the F-Link 2 is fully functional by performing a Postal Inspection and an OLS Generic call on the franking systems.


## LAN Wireless connectivity

The LAN Wireless connectivity works for the Frama Fx Series 7, 7.5 and 9.

## Connect by Wireless



Plug in the **Power Adapter** and wait until the status lights are lit



On your **Mobile Phone**, look in wireless setting for available networks. Search for a network that starts with: **Connect-A001245** Select this network and enter the **Password: Nconnect**

Open an internet browser on this phone and enter the following URL: **https://192.168.123.1**

You may see a warning that the connection is not private. Please click on the **Advanced-tab** in your browser to proceed to <https://192.168.123.1>

Now, you will be allowed to sign in. Use the following login:  
**Login: admin**  
**Password: admin**

## Configuration of Wireless mode for F-Link 2



HOME | NETWORK | LOG | INFO | SETTINGS | USER GUIDE  
 LAN | WIRELESS STATION | WIRELESS ACCESS POINT

Change parameters for Lan Interface

DHCP

Static

Ip address: 192.168.99.1

NetMask: 255.255.255.0

Gateway:

DNS 1: 8.8.8.8

DNS 2: 8.8.4.4

Submit

**Note:** With your mobile phone, you must be connected with the box to modify settings

### Step 1:

In the navigation, select **Network /LAN**

Next, set the following parameters:  
 Select **Static** (not DHCP)

Sample settings. Ask the Network administrator for correct IP credentials:

IP address: **192.168.99.1**  
 NetMask: **255.255.255.0**  
 Gateway:  
 DNS 1: **8.8.8.8**  
 DNS 2: **8.8.4.4**

Then, click the **Submit** button

### Step 2:

On **Settings / IS/IN/IX** enter **URL Settings** of F-Link 2

Connect HOME | NETWORK | LOG | INFO | SETTINGS | USER GUIDE  
 IS/IN/IX | IJ/WJ | PROXY | LOGIN/PWD | RESET

Change parameters for IS machine

Name server for On-Line Services: chfr-MeterServices.link0-neopost.com

Port number for On-Line Services: 443

Name server for Postal Core: chfr-MeterServices.link0-neopost.com

Port number for Postal Core: 443

Apply

### CH

On- Line Services: **chfr-MeterServices.link0-neopost.com**  
 Server Postal Core: **chfr-MeterServices.link0-neopost.com**  
 Port number: **443**

### UK

On- Line Services: **ukfr-MeterServices.link0-neopost.com**  
 Server Postal Core: **ukfr-MeterServices.link0-neopost.com**  
 Port number: **443**

Then, click the **Apply** button

The success information appears

**Note:** From configuration LAN to WI-FI, check in **Menu, advanced Network Settings:**  
**URI = OFF**  
**Port = 443**

### Step 3:

In the navigation, select **Wireless Station**. You will see a list of Wireless networks with their SSIDs displayed.

Select the corresponding Wireless network and click **Connect**

The security description is to be understood as follows:

- Open: no password required
- Secured: password required
- Secured Enterprise: administrator required

192.168.123.1 indique  
 connected to ssid: Livebox-AF90

OK

Connect HOME | NETWORK | LOG | INFO | SETTINGS | USER GUIDE  
 LAN | WIRELESS STATION | WIRELESS ACCESS POINT


Connect to a station

Choose	Station	dBm	Signal	Security
<input type="radio"/>	Livebox-AF90	-43.00	█	Secured
<input type="radio"/>	IOT10210b32u	-49.00	█	Secured
<input type="radio"/>	freebox_RQILYI	-71.00	█	Open
<input type="radio"/>	FreeWifi	-72.00	█	Open
<input type="radio"/>	FreeWifi_secure	-73.00	█	Secured Enterprise
<input type="radio"/>	AndroidAP5FBB	-95.00	█	Secured

Connect



Next, enter the **password** of your WLAN and click „**Connect**“




After that, you should receive a success information  
Press **OK**

**Note:** The WI-FI is activated if the green LED is lightnig

The F-Link 2 is now connected to WI-FI. Now, the configuration of the franking machine will take place.

### Configuration of Fx Series franking systems









Plug the LAN cable between the F-Link 2 and the franking systems

Power up the F-Link 2 if it's not already powered up



## Franking Systems Configuration



On the Franking Systems go to **Supervisor Mode (Manger)** and then to **Advanced Settings, Settings, Communication Setting** and configure following parameters

Next, select **LAN settings**

In Menu **DHCP configuration** select **DHCP Manual** to enter the fix IP

Following images showing **sample** IP setting. Ask your network administrator for correct credentials.

**Note:** with button **C** clear first all information being able to enter the IP address

- Machine IP address: **192.168.99.3**
- Subnet Mask: **255.255.255.0**
- Default Gateway: **192.168.99.1** (IP address of the F-Link 2)

Confirm with **OK** until you return to **DHCP manual** screen

Next enter **DNS settings**  
Select **Manual**


Enter **8.8.8.8** for the **preferred DNS** IP address

Press **OK**

Enter **8.8.4.4** for the **alternate DNS** IP address

Press **OK** until you reach **Proxy** screen

Select **Proxy off** and confirm with **OK**



The F-Link 2 is successfully setup once you see **both green lights** on



**Congratulation!** The F-Link 2 and the Franking Systems are successfully configured.  
However, make sure the F-Link 2 is fully functional by performing a Postal Inspection and an OLS Generic call on the franking machine.

# Appendix

## **To switch off Wi-Fi mode**

To disable the current Wi-Fi mode go to **Wireless Station**, press **Connect** and enter an incorrect **Password**. Wait until the message „Impossible to connect to ssid“: appears.

The green Wi-Fi Led turns to yellow. The chosen Wi-Fi station is disabled.

## **To Reset F-Link 2 to Factory Default**

### **Step 1:**

Connect a USB key (drive) to a PC. Make sure the key is formatted for FAT32.

### **Step 2:**

Create a text file on the root directory of the key and name it 'ifreset' then save.

Click on the new file and change the extension from '.txt' to '.cmd'.

Remove the key from the PC.

### **Step 3:**

Power off the F-Link 2 and insert the USB key into the USB port.

Switch On the F-Link 2.

Wait until the Wireless LED turns amber and the box has been reset.

## Specifications

### Connect Box Typ: A0124519

Connectivity:	RJ 45 Lan Connector USB 2.0 Host Connector
Core System:	CPU : NXP i.MX6UL @ 528MHz, ARM Cortex-A7, up to 1GB DDR3L
Power Specification:	Power Connector 5.5 / 2.1mm barrel jack External Power Supply 5V DC +/- 5% 1,2A Safety: UL/CUL,CB,GS,CE,FCC
Wireless Qualcomm:	Dual mode 802.11 a/b/g/n/ac up to 480Mbps. 2.4 Ghz FlexNotch Antenna
Wireless security:	WPA2-PSK, WPA-PSK
Compliants:	EN55032/24. CE, FCC Part 15C, ID 2AKZA-QCA9377, IC 22364-QCA9377
Speed:	Lan 10/100 Mbps
Temperature:	0° to 40°
Humidity Operating:	20% to 80%
Dimensions:	105 x 54 x 27 mn
Protocols/Port:	TCP/IP V4.0 TLS V1.2 / Port 443
Certificate:	Public
Key:	RSA key, 2048 bits