INSTALLING THE MATRIX F12

1. Unpack

Remove franking system, scales, consumables and cables from shipping box.

2. Connect mains lead

Connect the mains lead with the mains adapter. **Attention! Do not connect to the mains until power cable is attached to adaptor.**

3. Connect power supply

Connect the power supply (right-angle plug) to the franking system, as shown.

4. Connect the cables

Connect from the left to the right:
- The scale cable
- The network cable

5. Position the scales

Position the scales stand behind the franking system and place the scales on to it.

6. Position the catcher tray

Position the catcher tray on the left of the franking system.

7. Connect the franking system to the mains

Plug the franking system in to the mains. Wait for the start-up sequence to be completed.