


## INSPECTION

### 1. Connecting franking system with network




Make sure that the network connection is first set up correctly.

### 2. Select Account




Press "Admin" button in bottom right hand corner of screen.

### 3. Enter PIN




Enter your PIN (1234) and confirm with "OK" button.

### 4. Selecting further information




Main Menu: Press the "i" key in the top right of screen.

### 5. Select spanner option




Counter Readings: Select the spanner in the top right of screen.

### 6. Open Menu "Setup 2"




Menu Setup 1: Press the arrow top right.

### 7. Select "FramaOnline2"




Menu Setup 2: Select "FramaOnline2" bottom right of screen.

### 8. Selecting "Inspection"



Menu FramaOnline2: Select "Inspection" in the top left of screen.

### 9. Confirming Inspection



Menu Inspection: Confirm the question on the screen with "YES" button.

### 10. Finish Inspection



When the screen shows the message "Inspection successful", please touch the screen to continue.