



INSTALLATION OF INK-JET CASSETTE MATRIX F32-F82

1. Installation of Ink-Jet Cassette




Confirm the question on the screen with „YES“.

6. Print Alignment Y




Move to setting 2 (for example) with the - and + keys. Confirm entry with "ENTER".

2. Calibration of Ink-Jet Cassette




The Ink-Jet Cassette will be calibrated.

7. Repeat the Test Print




Repeat the Test Print.

3. Perform a Test Print




To perform a Test Print, insert a letter to produce an alignment Test Print.

8. Confirm



If the Test Print is correct, press "YES" to confirm the settings. Otherwise press "NO" to repeat.


4. Test Print



The Test Print shows current settings. The arrows should point to where the lines appear straightest.


Example:
Actual: X=-3 / Y=1
Should be: X=0 / Y=2

9. Print Alignment label



If the Label Box is inserted, perform a Test Print for the Label Box. Align the print also here if required (only X).

5. Print Alignment X



Move to setting 0 (for example) with the - and + keys. Confirm entry with "ENTER".