

REPLACING LABELS FOR MATRIX F42

1. Open the label dispenser



The label dispenser has a locked cover. Push the latch to the right with one finger to open the cover flap.

2. Remove the empty label box



Remove the empty label box.

3. New label box



Insert the new label box. Fix the labels in to the box using your finger (see arrow in example), push it in and to the left as far as it will go.

4. Close the label dispenser



Push the latch to the right and close the cover flap.